

## S



1. With the zCover trademark on the supporting disk facing you, insert the disk with the arrow pointing up through the screen opening.



Push the upper and lower pegs on the supporting disc into the holes on the back of zCover, the oval peg is for the upper hole.



3. Rotate the belt clip counterclockwise, and slide the bottom peg lock to the right as shown in the image.



4. Insert the oval peg into matching hole on the belt clip connector, and rotate the connector clockwise.



Insert the round peg into the bottom hole of the connector, and push the whole clip upward until both pegs reach the bottom of the peg slots.



To secure the belt clip, push the peg lock fully to the LEFT, then rotate the belt clip clockwise till it aligns with the connector. Warning: failure to do so will allow the clip to come loose.



7. Insert Treo into zCover through the screen opening as shown in the image.



8. Lift zCover right upper corner to cover the right upper side of Treo, first the back, and then the front.



9. Lift zCover upper left corner, gently thread the antenna through the antenna hole.

www.zcover.com Designed By zCover Inc. Canada 2005 All Rights Reserved.



10. Adjust zCover carefully to fit Treo as shown in the image.





zCover Screen Protector: Insert the upper Option 1. and lower parts of the screen protector into the gap between the Treo screen and Treo frame. Align the right and left parts of the protector to fit under the edges of the zCover screen opening.



Option 2. Stylus: Plug the zCover stylus in the Treo.



Option 3. Hand strap: Thread string loop through the hole at the top of the clip connector and tie the loop.